

## Foot Controls: Riding the Pedal

by Ralph L. Barnett

### ABSTRACT

The two predominant scenarios for accidentally tripping a foot control are stepping into the foot control and onto the pedal, i.e. "stepping contact" and keeping one foot on or just above the pedal at all times, i.e. "riding the pedal." This study shows that the various designs used to minimize "stepping contact" exacerbate inadvertent activation by "riding the pedal."

### 1. INTRODUCTION

Foot controls are used to activate machines in a variety of circumstances. A machine's productivity in the manual mode often requires that the operator's hands be utilized during the entire operational profile. A plethora of controls may require all of the operator's appendages. In situations where the hands can become entrapped, prudent safety management may require emergency stop foot switches or foot valves. Intervention systems for carpal tunnel syndrome arising from two hand hos-

tage controls may adopt foot controls. In all such cases there are periods where both hands may be exposed to point of operation hazards.

It is a universal admonition in machine design that controls be fashioned to minimize the probability of accidental activation. Tripping is the worry when foot controls are employed because operators seldom scrutinize the floor surface when they're working. This leads to inadvertent activation of the foot controls which produces unexpected start up of the machinery. This, of course, compromises the safety of both personnel and equipment and often destroys the workpiece being processed. Operators who are misusing the machines are usually protected during random cycling by point-of-operation guards or devices; maintenance personnel and bystanders are almost always at risk.

Old fashioned foot controls (circa 1930) would typically consist of a foot pedal located at a fixed station and disposed about six inches above the floor. Activation forces of over sixty five pounds were common and the associated pedal throw was about

three inches. With the advent of ergonomics, operator comfort, performance and convenience were addressed and the modern foot control emerged (Ref. 1-8).

Whereas the old fashioned foot controls were practically immune to "stepping contact," modern foot controls are a safety nightmare. These devices, which are tethered to machines by electric cords or pneumatic hoses, are placed or migrate throughout the operator's work space and constitute serious trip hazards. The pedals are located at an inch and a half above the floor. This distance makes the pedal particularly vulnerable to being stepped on since the normal walking gait brings the toe about two inches above the walking surface. Relatively speaking, the modern pedal is a "hair trigger" with a threshold force of about ten pounds and an associated activation throw in the neighborhood of 3/4 inches.

In response to the safety shortcomings of the modern foot control under misuse conditions (absence of point of operation safeguarding), manufacturers have introduced a variety of concepts

for minimizing inadvertent activation arising from "stepping contact." For example, top barrier guards, side shields, pedal locks, and front gates are used in various combinations. Unfortunately, as the intervention strategies become increasingly successful preventing "stepping contact," the foot control becomes more prone to the really insidious problem of "riding the pedal."

### II. THE TEST PROGRAM

Three foot control activation scenarios form the basis of our study:

1. *Riding the Pedal.* One foot is continually poised above or just touching the foot pedal until a machine stroke is required. The foot then depresses the foot pedal eventually returning to its position above the pedal. It is never withdrawn from the foot control. "Riding the pedal" is analogous to hunters "keeping their finger on the trigger." Riding the pedal is the most prevalent cause of accidental activation of power presses. When power press

\*Professor, Mechanical and Aerospace Engineering, Illinois Institute of Technology, Chicago, and Chairman of the Board, Triodyne Inc., Niles, IL.

Foot Controls	1	2	3	4	5	6	7	8	9	10	11	12
Reciprocating Strokes/30 sec.	Avg. 48.72 St'd Dev. 8.95	Avg. 48.36 St'd Dev. 10.40	Avg. 47.66 St'd Dev. 12.59	Avg. 46.69 St'd Dev. 7.73	Avg. 46.44 St'd Dev. 8.41	Avg. 46.30 St'd Dev. 9.58	Avg. 44.69 St'd Dev. 10.29	Avg. 36.66 St'd Dev. 6.97	Avg. 32.82 St'd Dev. 6.23	Avg. 28.86 St'd Dev. 6.02	Avg. 25.50 St'd Dev. 4.61	Avg. 16.94 St'd Dev. 3.80
Pivoting Strokes/30 sec.	Avg. 47.06 St'd Dev. 8.90	Avg. 44.89 St'd Dev. 8.58	Avg. 42.03 St'd Dev. 11.70	Avg. 43.86 St'd Dev. 7.91	Avg. 45.75 St'd Dev. 8.63							
Characteristics Height: Width: Min. Force: Throw:	3.0 in. Open Sides 7.0 lbs. 0.375 in.	3.0 in. Open Sides 12.0 lbs. 0.5 in.	2.625 in. Open Sides 5.0 lbs. 0.5 in.	2.625 in. Open Sides 7.5 lbs. 0.75 in.	3.5 in. 6.0 in. 0.75 lbs. 0.625 in.	2.75 in. 5.625 in. 8.0 lbs. 1.0 in.	3.5 in. 5.25 in. 9.75 lbs. 0.75 in.	2.75 in. 5.50 in. 13.0 lbs. 0.875 in.	2.75 in. 5.50 in. 13.0 lbs. 0.875 in.	2.75 in. 5.25 in. 9.5 lbs. 0.5 in.	2.875 in. 4.875 in. 10.0 lbs. 0.375 in.	2.75 in. 5.625 in. 8.0 lbs. 1.0 in.

Fig. 1 Foot Control Stroke Rates and Characteristics

DEFENDANT'S  
EXHIBIT  
P  
04-249E

6. As we move from left to right in Fig. 1, the foot controls pose a decreasing likelihood of an accidental "stepping contact." The easier it is to activate a control inadvertently, the easier it is to trip it inadvertently. The speed provoked rate is observed to decrease as one progresses from models one through twelve.

7. Conclusion 6 may be partially corroborated by simple geometric and functional observations. If candidates 10 and 11 are removed from the set, it is clear that increasingly severe foot insertion obstacles are being incorporated into the foot controls as one moves from left to right in Fig. 1. Even the extra wide Schrader shows up as the best of the three side-shielded models (5, 6, and 7). Candidates 10 and 11 cannot be ranked by qualitative observations; the actual detailed gate design plays an important role.

8. The resistance to accidental "stepping contact" is inversely related to the propensity for "riding the pedal."

9. The proper selection of a foot control is not straightforward. It involves many considerations including a knowledge of operator movement in the work space, steadiness requirements for part insertion, the use of point-of-operation safeguarding, technology transfer, maximum or continuous stroke rate of the controlled machine and the various anticipated uses of the foot control on multi-mode machinery.

## REFERENCES

1. Corlett, E.N., and R.P. Bishop. 1975. "Foot Pedal Forces for Seated Operators." *Ergonomics* 18, no. 6 (November): 687-697.
2. Krcmar, K.H.E. 1971. "Foot Operation of Controls." *Ergonomics* 12, no. 3 (May): 333-361.
3. Trombley, D.J. 1966. "Experimental Determination of an Optimal Foot Pedal Design." Report, Dureau, Lubbock, TX: Central Library Texas Technological College. (Abstract in AIEE Transactions.)
4. Siemens Schuckertwerke AG. 1965. "Kafte an Frieschaltigen Bedienungseinheiten." (Focus on Foot-Operated Devices). In *German Siemens Report No. 7/64/FV7 Mitteilung aus dem Arbeitswissenschaftlichen Labor (Bspontest)*, 18 pp.
5. Ayoub, M.M., and D.J. Trombley. 1967. "Experimental Determination of an Optimal Foot Pedal Design." *Journal of Industrial Engineering* 18 (September): 550-559.
6. Docter, H.J. 1986. "The Ergonomic Aspects of Working with the Pedals in Industry." In *Dutch Tijdschr. soc. Geneesk* 44, no. 16, pp. 628-636. Section 17 in *Excerpta med.* 13 (March 1967): 280.
7. Docter, H.J. 1966. "Ergonomic Aspects of Operating Pedals in Industry." In *Dutch Tijdschr. soc. Geneesk* 44, no. 17, pp. 666-671. Section 17 in *Excerpta med.* (February 1967): 193.
8. Barnes, Ralph M. Henry Hardaway, and Orl Podestsky. 1942. "Which Pedal is Best?" *Factory Management and Maintenance* 100, no. 1 (January): 98-99.

## SAFETY BRIEF

July 1997 - Volume 13, No. 1

Editor: Paula L. Barnett

Illustrated and Produced by Triodyne Graphic Communications Group

Copyright © 1997 Triodyne, Inc. All Rights Reserved. No portion of this publication may be reproduced by any process without written permission of Triodyne, Inc., 5950 West Touhy Avenue, Niles, IL 60714-4610 (847) 677-4730. Direct all inquiries to: Library Service.

vation of this foot control is generally perceived as a two-step process: unlatch and depress. As it turns out, however, experienced operator's hit the latch and pedal in a single motion. Inadvertent partial insertion of the foot will not trip this control.

### 4. Lift Gate

Candidates 9, 10, and 11 are protected in part by front gates which must first be lifted by the toe to gain access to the foot pedal which in turn must be depressed to activate the foot control. This two-step procedure inhibits both normal and accidental activation by "stepping contact." The gate is effective in minimizing inadvertent intrusion; it does not, however, eliminate the problem. The lower edge of the front flap has a ski nose to help the "camel get his nose under the tent." Striking the ski nose hard with a flat toe shoe will almost always defeat the liftable gate and allow a one motion activation. Candidate 9 combines the liftable gate with a pedal lock. Theoretically, activation is a three step process; lift the gate, unlatch the lock and depress the pedal. As a practical matter, the ski nose enables the process to be accomplished using a single forceful motion.

### 5. The Drawbridge Flap

Foot control candidate 12 virtually eliminates "stepping contact." Here, a flap is hinged along the bottom and a spring constantly urges the drawbridge type door to its vertical deployed position. Any force applied to the face of the flap closes it tighter. On the other hand, the control is relatively difficult to use. The flap is opened by dragging its upper edge backward with the sole of the shoe. The operator then inserts the foot which is holding the flap open and depresses the pedal to activate the control. The operator's weight is supported on one leg during this process. Proper deactivation of the switch requires the complete removal of the foot which should then be placed on the floor allowing the flap to close. Avoiding continual reopening of the flap requires that the door be continuously held open against its spring closure force. Safety is not promoted by the constant application of a downward force in the neighborhood of the control pedal. Observe that candidate 6 is obtained by taping the flap open on candidate 12. An almost three-fold increase in the stroke rates follows.

## IV CONCLUSIONS

1. The reciprocating mode is slightly more efficient than the pivoting mode.
2. There is little difference in efficiency among the first seven candidates which allow for simple reciprocating activation.
3. The efficiency of the open-sided models as a group is slightly greater than the side-shielded candidates represented by models 5, 6, and 7.
4. The open-sided models allow operators to deal with fatigue and discomfort by switching between two almost equally efficient activation strategies: pivoting and reciprocating. The side-shielded candidates offer only "riding the pedal" as an alternate activation method.
5. The motivation to "ride the pedal" increases as one moves from left to right in Fig. 1. Stroke speed decreases by a third. The more difficult it is to step into and out of a foot control, the more likely it is that operators will "ride the pedal."

six male students. Candidate 6 was tested in 1977; the test was repeated three times by each of sixteen male students. In 1984, candidate 9 was tested by nineteen male students who repeated the trial three times.

Foot controls are grouped below according to the safeguarding systems used to minimize accidental tripping from "stepping contact."

### 1. Top Guard

Top guards preclude foot control activation from the rear and top. Candidates 1, 2, 3, and 4 are top guarded controls. They may be activated and deactivated from both the front and sides using the reciprocating or pivoting scenarios. Further, they accommodate wide footwear. These utilitarian features also have safety overtones. First, they reduce fatigue by allowing the operator to alternate activation strategies. Second, foot removal is uninhibited leading to very rapid emergency stop commands. Finally, the foot cannot be blocked by a rolling cart, box or other obstruction to prevent deactivation. Power presses often have a continuous mode that requires constant depression of the foot pedal. The operator intercedes during an emergency by removing his foot from the control.

### 2. Top Guard and Side Shields

These safeguards are used by candidates 5, 6, and 7. Access to the foot pedal is blocked on the sides which helps reduce "stepping contact." On the other hand, the side shields inhibit somewhat the force movement of the foot during reciprocation. Unlike the open sided candidates, the pivoting mode is usually not available for relief of fatigue from the reciprocating action. Riding the pedal provides the only feasible respite.

### 3. Pedal Lock

Candidates 8 and 9 are constructed with a pedal latch that will lock the pedal unless the foot is fully inserted into the foot control and pushed rearward against a vertical plate. After unlatching in this manner, the pedal is depressed to activate the control. Activation




Fig. 2 Foot Control Characteristics

operators keep their foot deployed over the pedal, accidental activation may occur during sneezing, reaching forward, slipping, and from foot fatigue or being bumped forward.

2. *Pivoting*: Starting with both feet on the floor, one foot is pivoted about the heel and swung into the foot control. It then depresses the foot pedal and swings back into its original position on the floor. "Riding the pedal" does not occur; furthermore, the active foot never lifts or shifts its heel. This strategy is usually available only with open-sided controls. Although side shielded, it was feasible to use the pivot mode with the Schrader foot valve because of its exceptional width (6 inches).

3. *Reciprocating*: Starting with both feet on the floor, one foot is inserted into the foot control by a forward movement followed by a depression onto the pedal. This foot is then moved rearward into its original (starting) position. "Riding the pedal" does not occur. During reciprocating, all of the operator's weight is supported by the non-active foot. This operating mode may be used with either open-sided or side shielded controls.

Our investigation began with the observation that:

*The more difficult it is to step into and out of a foot control, the more likely it is that operators will "ride the pedal."*

One method of quantifying "activity difficulty" is to measure the maximum stroke rate under speed provoking conditions. Accordingly, a test protocol was formulated for the pivoting mode and the reciprocating mode with the following characteristics:

**Participants:** Male and female senior engineering students. Only the results of the males are recorded in this study.

**Goal:** For each foot control candidate the students tried their personal best to maximize the number of activation strokes in a thirty second period. This short time interval was selected to eliminate endurance effects which are not encountered in the workplace.

**Position:** Each foot control was fixed in location. The students operated the controls from a free standing position. **Practice:** One practice run was performed for each foot control candidate.

**Fidelity:** Strict adherence to the definitions of pivoting and reciprocating was enforced by fellow students.

**Incentive:** Striving for one's personal best score was influenced by the following factors:

- The students were proctored by the class professor.
- The test program was conducted as a contest with published results.
- Peer pressure
- Machismo

## III. TEST RESULTS

Using the test protocol, stroke rates were determined for the twelve foot controls shown in Fig. 1. They are illustrated in descending order of the stroke rate obtained in the reciprocating mode. The first five controls can be activated in the pivoting and reciprocating modes and the associated stroke rates are listed for both. Foot control characteristics illustrated in Fig. 2 are tabulated in Fig. 1. A minimum force is recorded for each candidate that represents the force applied to the lip of the foot pedal which just activates the control. In 1980, the candidate foot controls 1, 2, 3, 4, 5, 7, 8, 10, 11, and 12 were tested one time by each of thirty-